

FRONT SHOCK
ABSORBER
MOUNTING
BRACKET
TO SHOCK
TOWER NUTS

