



**INSTALL REAR SHOCK ABSORBER  
18125 WITH TWO NEW NUTS**