

POSITION
REAR
SPRING
INSULATOR
5536

REAR SPRING
END

STEP IN
SPRING
SEAT
POCKET

SHOCK
ABSORBER
18080

SPRING END MUST BE
WITHIN 10mm (0.39 INCH) OF
STEP IN SPRING SEAT

