

CAUTION: WOOD BLOCK MUST BE USED TO SUPPORT SUSPENSION ARMS. BLOCK SHOULD NOT TOUCH BRAKE DRUM

