

SNAP LARGE TAB INTO WHEEL
PRIOR TO INSTALLING SCREWS

BOLT
N805167-S100
TIGHTEN TO
31-45 N·m
(23-33 LB-FT)

HORN PAD ASSY
13K802

3600 ASSY (BASE)
3F563 ASSY (LEATHER WRAP)

SCREW
56902-S2
2 REQ'D
TIGHTEN TO
.56-1.13 N·m
(5-10 LB-IN)

STEERING WHEEL HUB
COVER AND HORN SWITCH
ASSY 13K802

3600 ASSY

BOLT
N805167
TIGHTEN TO
31-45 N·m
(23-33 LB-FT)

SCREW
55927-S2
2 REQ'D
TIGHTEN TO .56-1.13 N·m
(5-10 LB-IN)

BASE WHEEL TAURUS

