



- | | |
|----------------------------|--|
| 1. Hose assembly | 6. Engine air intake resonator |
| 2A. Screw (2 required) | 7. Manifold assembly |
| 3. Engine air cleaner | 8. LH fender apron |
| 4. Battery tray | A. Tighten to 2.7-5.4 N·m
(24-47 lb-in) |
| 5. Air cleaner outlet tube | |