

- 1. Engine air intake resonator
- 2. LH fender
- 3. Engine air cleaner 4A. Screw
 - 5. Air cleaner cover retainer clip
- 6B. Bolt
- 7C. Clamp assembly (2 required) 8. Throttle body
- 10D. Nut and washer assembly 11. Cowl
 - A. Tighten to 12-18 N.m (9-13 lb-ft)
 - B. Tighten to 8-11 N.m (6-8 lb-ft) C. Tighten to 1.4-2.3 N.m (12-20 lb-in)
 - D. Tighten to 5-5.7 N.m (49-62 lb-in)