

CHECK FLUID LEVEL AT  
OPERATING TEMPERATURE  
ONLY 66°C TO 77°C  
(150° TO 170°F)



DO NOT  
DRIVE MARK

BRAKE MASTER  
CYLINDER RESERVOIR

POWER STEERING  
PUMP DIPSTICK  
FLUID SHOULD BE  
IN THE FULL COLD  
OR FULL HOT RANGE  
DEPENDING UPON  
TEMPERATURE

AUTOMATIC TRANSAXLE  
OIL LEVEL INDICATOR  
ATF MERCON®  
CHECK WITH ENGINE  
RUNNING AND IN PARK

RADIATOR COOLANT  
RECOVERY RESERVOIR

WINDSHIELD  
WASHER  
RESERVOIR

ENGINE OIL  
LEVEL INDICATOR

AIR CLEANER  
ELEMENT FA1043  
REPLACE ELEMENT  
AT RECOMMENDED  
INTERVALS

MAINTAIN OIL IN  
SAFE RANGE


RADIATOR CAP

OIL FILLER CAP

BATTERY  
BXT-65-650  
BXT-65-850 (OPTIONAL)



DO NOT ADD  
OIL BEYOND  
"FULL"



OIL FILTER  
FL400A  
COAT GASKET WITH ENGINE  
OIL. REPLACE FILTER AT  
RECOMMENDED INTERVAL

