

NOTE: DO NOT REUSE SPRING CLAMPS.
REPLACE WITH SCREW TIGHTENED CLAMPS.

- 1. Heater hot water tube
- 2. Bolt
- 3. Heater water hose
- 4. Hose clamp

- 5. Heater water hose
- 6. Heater hot water tube
- 7. Main wiring