



- 1 Ignition wire (6 req'd)
- 2 Ignition coil cover
- 3 Screw (4 req'd)
- 4 Ignition coil
- 5 Ignition coil bracket
- 6 Bolt (2 req'd)
- 7 Screw (3 req'd each side)

- 8 Spark plug (6 req'd)
- 9 Ignition wire separator
- 10 Valve cover
- 11 Radio ignition interference capacitor
- A Tighten to 4.5-7.0 Nm (40-62 lb.in.)
- B Tighten to 28-42 Nm (21-31 lb.ft.)