

EVP SENSOR
9G428

TO VACUUM
SOURCE
(EGR SOLENOIDS)

EGR VALVE
9H473

FLOW

EGR VALVE
AND SENSOR
ASSEMBLY
9F483

EXHAUST GAS INLET

SIDE (EXTERNAL) ENTRY TYPE

