



COLON DISPLAY

FLASHES




STEADY



**COLON MUST BE DISPLAYED TO
RECEIVE SERVICE CODES**

LO BAT INDICATOR



**IF LO BAT SHOWS STEADILY WITH
SERVICE CODE, REPLACE TESTER'S 9V
BATTERY**