



ENGINE VACUUM REFERENCE TUBE

VALVE ASSY

BALL SEAT

SPRING

SPRING SEAT

UPPER HOUSING

FUEL FILTER SCREEN

DIAPHRAGM

MOUNTING PLATE

LOWER HOUSING

O-RING GROOVE

FUEL INLET TUBE (SUPPLY)

FUEL OUTLET TUBE (RETURN)