

- 1. Fuel pressure relief valve cap
- 2. Fuel pressure relief valve
- 3. Bolt
- 4. Fuel injector supply manifold bracket
- 5. Fuel injection supply manifold connector
- 6. Intake manifold support
- 7. Bolt (4 required)
- 8. Fuel injection supply manifold (2 required)

- 9. Fuel injector (6 required)
- 10. Fuel injection pulse dampener
- 11. Fuel supply and return lines
- 12. Bolt (2 required)
- 13. Fuel pressure regulator
- 14. Bolt union (2 required)
- A. Tighten to 0.6 N.m (5.3 lb-in)
- B. Tighten to 7.75 N.m (69 lb-in)
- C. Tighten to 15-23 N.m (11-17 lb-ft)
- D. Tighten to 25-34 N.m (18-25 lb-ft)