

- 1. Fuel and vapor return tube
- 2. Fuel supply line
- 3. Flexible fuel sensor
- 4. Fuel mixer
- 5. Screw (2 required)
- 6. Flexible fuel sensor bracket
- A. Tighten to 8-11 N.m (70-97 lb-in)

