



- 1 Instrument cluster
- 2 Engine coolant temperature gauge
- 3 Speedometer
- 4 Odometer reset shaft
- 5 Fuel gauge
- 6 Safety belt indicator
- 7 Liftgate ajar indicator (wagon only)
- 8 Air bag readiness indicator lamp
- 9 Malfunction indicator lamp (MIL)

- 10 RH turn signal indicator
- 11 Transmission range indicator (automatic transaxle only)
- 12 LH turn signal indicator
- 13 High beam indicator
- 14 Charging system indicator
- 15 Anti-lock indicator (optional)
- 16 Low oil pressure indicator
- 17 Brake system indicator