



FRONT WHEEL
DRIVESHAFT
JOINT BOOT
CLAMP
SMALL 3B478

FRONT WHEEL
DRIVESHAFT
JOINT BOOT
3A331



INSTALL END
OF BOOT IN
THE GROOVE

LOCATE CLAMP TABS IN
SLOTS. MAKE FRONT
WHEEL DRIVE SHAFT
JOINT BOOT CLAMP
3B478 AS TIGHT AS
POSSIBLE BY HAND



TOOL
T95P-3514-A

