



- 1 Arbor press
- 2 Bearing replacer (must be positioned with undercut side facing bearing)
- 3 Front wheel knuckle - outboard side
- 4 Face plate
- 5 Step side down
- 6 Front bearing spacer
- 7 Front wheel bearing