

WHEEL ALIGNMENT

Year	Model		Caster		Camber		Toe-in (in.)	Steering Axis Inclination (deg.)
			Range (deg.)	Preferred Setting (deg.)	Range (deg.)	Preferred Setting (deg.)		
1986	Taurus	F	3P-6P	4P	1 3/32N-3/32P	1/2N	3/32N	15 3/8
		R	-	-	1 5/8N-1/4N	15/16N	1/16P	-
	Sable	F 1 R 1	3P-6P -	4P -	1 3/32N-3/32P 1 5/8-1/4N	1/2N 15/16N	3/32N 1/16N	15 3/8 -
1987	Taurus	F	3P-6P	4P	1 3/32N-3/32P	1/2N	3/32N	15 3/8
		R 1	-	-	1 5/8N-1/4N	15/16N	1/16P	-
	Sable	F 1 R 1	3P-6P -	4P -	1 1/32-3/32P 1 5/8-1/4N	1/2N 15/16N	1/16N 3/32N	15 3/8 -
1988	Taurus	F	3P-6P	4P	1 3/32P-3/32P	1/2N	3/32N	15 3/8
		R 1	-	-	1 5/8N-1.4N	15/16N	1/16P	-
	Sable	F 1 R 1	3P-6P -	4P -	1 1/32-3/32P 1 5/8-1/4N	1/2N 15/16N	1/16N 3/32N	15 3/8 -
1989	Taurus	F 1	2 13/16P-5 131/6P	3 13/16P	1/18N-1/8P	1/2N	3/16N	15 1/2
		F 2	2 11/16P-5 11/16P	3 11/16P	1 7/8P-1/8N	7/8N	3/16N	15 1/2
	Sable	F 1 R 1	2 13/16P-5 131/6P -	3 13/16P -	1 1/8N-1/8P 1 5/8N-7/32N	1/2N 15/16N	3/16N 1/16P	15 1/2 -
1990	Taurus	F 1	2 13/16P-5 13/16P	2 13/16P	1 1/8N-1/8P	1/2N	3/32N	15 1/2
		F 2	2 5/8P-4 5/8P	3 5/8P	1 1/16N-3/16P	7/16N	3/32N	15 1/2
	Sable	F 1 R 1	2 13/16P-5 13/16 P -	2 13/16P -	1 1/8N-1/8P 1 5/8N-7/32N	1/2N 15/16N	3/32N 1/16P	15 1/2 -
1991	Taurus	F 1	2 13/16P-5 13/16P	2 13/16P	1/18N-1/8P	1/2N	3/32N	15 1/2
		F 2	2 5/8P-4 5/8P	3 5/8P	1 1/16N-3/16P	7/16N	3/32N	15 1/2
	Sable	F 1 R 1	2 13/16P-5 13/16 P -	2 13/16P -	1 1/8N-1/8P 1 5/8N-7/32N	1/2N 15/16N	3/32N 1/16P	15 1/2 -
1992	Taurus	F 1	2 31/6P-5 13/16P	2 13/16P	1 1/8N-1/8P	1/2N	3/32N	15 1/2
		F 2	2 11/16P-4 11/16P	3 11/16P	1N-1/4P	3/8N	3/32N	15 1/2
	Sable	F 1 R 1	2 13/16P-5 13/16 P -	2 13/16P -	1 1/8N-1/8P 1 5/8N-7/32N	1/2N 15/16N	3/32N 1/16P	15 1/2 -