



**NOTE: LOCK ACTUATOR ASSY
WILL SLIDE OUT WHEN
IGNITION SWITCH IS REMOVED**

**REMOVE IGNITION
SWITCH AND COVER**