



Item	Part Number	Description
1	—	Boot (Part of 2261)
2	—	Spring Expander (Part of 2261)
3	2261	Rear Wheel Cylinder
4	—	Piston and Insert (Part of 2261)
5	—	Shoe Adjustment Access Hole
6	N801327	Wheel Cylinder Retaining Screw (2 Req'd)
7	2092	Brake Adjusting Hole Cover
8	2069	Brake Shoe Hold Down Spring Pin
9	2211	Brake Backing Plate
10	—	Trailing Shoe and Lining (Part of 2200)
11	2068	Brake Shoe Hold-Down Spring
12	2035	Lower Brake Shoe Retracting Spring
13	2A637 (RH) 2A638 (LH)	Parking Brake Lever

Item	Part Number	Description
14	2107	Parking Brake Lever Pin (Inner)
15	2048	Brake Shoe Adjusting Screw Socket
16	2A177 (LH) 2A176 (RH)	Brake Shoe Adjusting Lever
17	2107	Parking Brake Lever Pin
18	—	Leading Shoe and Lining (Part of 2001)
19	2049	Brake Shoe Adjusting Screw Spring
20	—	Cup (Part of 2261)
21	384373-S	Washer
22	—	Adjusting Screw (Part of 2261)
23	356297-S2	Washer
24	2106	Parking Brake Lever Pin Retainer
25	—	Adjusting Pivot Nut (Part of 2048)
A	—	Tighten to 10-14 N·m (8-10 Lb·In)