

Trim Panels, Door—Front

Removal and Installation

1. Remove window regulator handle (23342) by unsnapping handle cover from base to expose retaining screw. Remove screw, window regulator handle and window regulator handle

