
BLADE ASSY
VIEW B
ARM ASSY
ARM ASSY LH
VIEW A
WIPER ARM STOP
(PART OF LEAF SCREEN)
SCREEN ASSY
ARM AND PIVOT
SHAFT ASSY
ARM AND
PIVOT SHAFT
ASSY
LATCH TAB
(SHOWN IN OPEN
(OUTWARD) POSITION)
VIEW A
NOTE: TO RELEASE, INSERT
SCREWDRIVER INTO SLOT
AND PUSH DOWN ON SPRING
ARM ASSY
ARM ASSY
TRICO
VIEW B