
IGNITION SWITCH
RED/LT GRN
IGN COIL FUSE 10A
HOT AT ALL TIMES
COOLING FAN FUSE 50A
BLK/ORG
CONSTANT CONTROL RELAY MODULE
NOISE CAPACITOR
IGNITION COIL
SPARK PLUGS
BLK
TAN/YEL
TO INSTRUMENT CLUSTER
DISTRIBUTOR
BRN/ORG
DK BLU
ELECTRIC COOLING FAN
A/C CLUTCH COIL
BLK/YEL
YEL
PNK/LT BLU
TO A/C SYSTEM
PNK/BLK
LT BLU/ORG
INERTIA FUEL SHUTOFF SWITCH
FUEL PUMP/ FUEL GAUGE SENDER
TAN/ORG
LT GRN/PPL
PNK/YEL
HOT AT ALL TIMES
PCM RELAY/ FUEL PUMP FUSE 30A
BLK/LT GRN
GRY/ORG
BLK/WHT
IGNITION CONTROL MODULE
TO AX4N/AX4S TRANSAXLE
RED
TO DATA LINK CONNECTOR
CANISTER PURGE SOLENOID
EGR VAC. REG. SOL.
INJ. 1
INJ. 2
INJ. 3
INJ. 4
INJ. 5
INJ. 6
IDLE AIR CNTRL SOL.
TAN/RED
YEL/LT GRN
SPOUT CHECK CONN.
MASS AIR FLOW SENSOR
BLK/LT GRN
LT BLU/RED
TAN/LT BLU
WHT/PNK
GRY
TO INSTRUMENT CLUSTER
LT BLU/PNK
TO EXTERIOR LIGHTS SYSTEM
RED/LT GRN
BRN/LT BLU
LT GRN/ORG
LT BLU/ORG
YEL
GRY/YEL
BRN/PNK
TAN
WHT
BRN/YEL
TAN/BLK
BRN/WHT
34
16
56
36
4
50
9
11
2
57
37
33
58
59
39
35
15
12
21
22
17
1
8
13
31
54
POWERTRAIN CONTROL MODULE
7
10
47
48
26
27
28
46
25
38
49
51
53
52
55
5
30
44
18
19
43
40
60
6
3
20
PNK/LT BLU
TO A/C SYSTEM
LT GRN/RED
BRN
TO STI DATA LINK CONNECTOR
BRN/WHT
BRN/LT GRN
GRY/WHT
YEL/LT GRN
ENGINE COOLANT TEMP. SENSOR
THROTTLE POSITION SENSOR
PRESSURE FEEDBACK EGR SENSOR
POWER STEERING PRESSURE SWITCH
GRY/RED
TO DATA LINK CONNECTOR
GRY/RED
GRY
GRY/RED
ORG/BLK
WHT/YEL
ORG/YEL
TAN/WHT (MID- YEAR) PPL/YEL
PPL/ORG
WHT/RED (MID- YEAR) PNK/BLK
GRY/BLK
TO AX4N/AX4S TRANSAXLE
INTAKE AIR TEMP. SENSOR
TURBINE SHAFT SPEED SENSOR
LT BLU/YEL
GRY/LT BLU
TRANS. RANGE SENSOR
TAN/ORG
TO DATA LINK CONNECTOR
HOT IN RUN
FUSE 5 15A
PPL/ORG
HEATED OXYGEN SENSOR #1
BLK/LT GRN
BLK/LT GRN
BLK/LT GRN
RED/BLK
BLK/LT GRN
BLK
ORG/YEL
DK GRN/WHT
VEHICLE SPEED SENSOR
BLK
HEATED OXYGEN SENSOR #2
GRY/RED